


Caliper adapter mounting instructions


This manual applies to article: 211045 - 211054 - 211057 - 211061 - 211063 - 211095 - 211096 - 211097 - 211126 - 211130 - 211131 - 211137 - 211138 - 211140

Front Fork up to and including 2014




Use your motorcycle's original (OEM) M8 x 35 mm bolts to mount the caliper adapter bracket. Do not use the included Moto-Master bolts.

Front Fork from 2015 - and up



Use the included Moto-Master M8 x 27.5 mm bolts to mount the caliper adapter bracket.



For more info, check:

WWW.MOTO-MASTER.COM/DOWNLOADS